

MÄSER
GROUP
TABLEWARE SOLUTIONS








KITCHEN *time*





KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	335000	Ramequin 9 cm, round, BLUE	NO	A6	STK
	335001	Ramequin 9 cm, round, GREEN	NO	A6	STK
	335002	Ramequin 9 cm, round, GREY	NO	A6	STK
	335003	Ramequin 11 cm, round, BLUE	NO	A6	STK
	335004	Ramequin 11 cm, round, GREEN	NO	A6	STK
	335005	Ramequin 11 cm, rund, GRAU	NO	A6	STK
	335006	Mini baking dish 21 x 12 cm, rectangular, BLUE	NO	A6	STK
	335007	Mini baking dish 16,5 cm, round, BLUE	NO	A6	STK



KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	335008	Mini baking dish 16,5 cm, round, GREEN	NO	A6	STK
	335009	Mini baking dish 16,5 cm, round, GREY	NO	A6	STK
	335010	Mini baking dish 21 x 12,5 cm, rectangular, GREEN	NO	A6	STK
	335011	Mini baking dish 21 x 12,5 cm, rectangular, GREY	NO	A6	STK
	335012	Mini baking dish 20,5 x 11,5 cm, oval, BLUE	NO	A6	STK
	335013	Mini baking dish 20,5 x 11,5 cm, oval, GREEN	NO	A6	STK
	335014	Mini baking dish 20,5 x 11,5 cm, oval, GREY	NO	A6	STK
	335015	Baking dish 28 x 19 cm, oval, BLUE	NO	A6	STK



KITCHEN-TIME









Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	335016	Baking dish 28 x 19 cm, oval, GREEN	NO	A6	STK
	335017	Baking dish 28 x 19 cm, oval, GREY	NO	A6	STK
	335018	Baking dish 36,5 x 23,5 cm, oval, BLUE	NO	A4	STK
	335019	Baking dish 36,5 x 23,5 cm, oval, GREEN	NO	A4	STK
	335020	Baking dish 36,5 x 23,5 cm, oval, GREY	NO		STK
	335021	Baking dish 25,5 x 17,5 cm, rectangular, BLUE	NO	A6	STK
	335022	Baking dish 25,5 x 17,5 cm, rectangular, GREEN	NO	A6	STK
	335023	Baking dish 25,5 x 17,5 cm, rectangular, GREY	NO	A6	STK



KITCHEN-TIME







Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	335024	Baking dish 33 x 24 cm, rectangular, BLUE	NO	A4	STK
	335025	Baking dish 33 x 24 cm, rectangular, GREEN	NO	A4	STK
	335026	Baking dish 33 x 24 cm, rectangular, GREY	NO	A4	STK
	335027	Egg dish 18 x 14 cm BLUE	NO	A6	STK
	335028	Egg dish 18 x 14 cm GREEN	NO	A6	STK
	335029	Egg dish 18 x 14 cm GREY	NO	A6	STK
	335030	Egg dish 22 x 18 cm BLUE	NO	A6	STK
	335031	Egg dish 22 x 18 cm GREEN	NO	A6	STK



KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	335032	Egg dish 22 x 18 cm GREY	NO	A6	STK
	335033	Soufflé 20,5 cm BLUE	NO	A6	STK
	335034	Soufflé 20,5 cm GREEN	NO	A6	STK
	335035	Soufflé 20,5 cm GREY	NO	A6	STK
	335036	Tarte 27 cm BLUE	NO	A6	STK
	335037	Tarte 27 cm GREEN	NO	A6	STK
	335038	Tarte 27 cm GREY	NO	A6	STK



KITCHEN-TIME


Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	513010	Coffee cup 25 cl BLUE	NO	A6	STK
	513011	Coffee saucer 14,5 cm BLUE	NO	A6	STK
	513012	Espresso cup 9 cl BLUE	NO	A6	STK
	513013	Espresso saucer BLUE	NO	A6	STK
	513014	Coffee mug 36,5 cl BLUE	NA	A6	STK
	513015	Bowl 14 cm BLUE	NO	A6	STK
	513016	Soup plate 21,5 cm BLUE	NO	A6	STK
	513017	Dinner plate 24 cm BLUE	NO	A6	STK



KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	513018	Dessert plate 20,5 cm BLUE	NA	A6	STK



KITCHEN-TIME


Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	513030	Coffee cup 25 cl GREEN	NO	A6	STK
	513031	Coffee saucer 14,5 cm GREEN	NO	A6	STK
	513032	Espresso cup 9 cl GREEN	NO	A6	STK
	513033	Espresso saucer GREEN	NO	A6	STK
	513034	Coffee mug 36,5 cl GREEN	NA	A6	STK
	513035	Bowl 14 cm GREEN	NO	A6	STK
	513036	Soup plate 21,5 cm GREEN	NO	A6	STK
	513037	Dinner plate 24 cm GREEN	NO	A6	STK



KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	513038	Dessert plate 20,5 cm GREEN	NA	A6	STK



KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	513050	Coffee cup 25 cl GREY	NO	A6	STK
	513051	Coffee saucer 14,5 cm GREY	NO	A6	STK
	513052	Espresso cup 9 cl GREY	NO	A6	STK
	513053	Espresso saucer GREY	NO	A6	STK
	513054	Coffee mug 36,5 cl GREY	NA	A6	STK
	513055	Bowl 14 cm GREY	NO	A6	STK
	513056	Soup plate 21,5 cm grey	NO	A6	STK
	513057	Dinner plate 24 cm GREY	NO	A6	STK



KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	513058	Dessert plate 20,5 cm GREY	NA	A6	STK



KITCHEN-TIME

Kitchen Time

DOMESTIC®
by MÄSER



Item No.	Description	RKZ	PU	PCS
808158	24 pcs. cutlery set	NO	C1/B12	C1



KITCHEN-TIME








Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	814270	16 cm non-stick sauce pan, BLUE	NO	SC1	SC1
	814271	16 cm non-stick sauce pan, GREEN	NO	SC1	SC1
	814272	16 cm non-stick sauce pan, GREY	NO	SC1	SC1
	814273	16 cm casserole with glass lid, BLUE	IO	SC1/B6	SC1
	814274	20 cm non-stick casserole with glass lid, GREEN	IO	SC1	SC1
	814275	24 cm non-stick casserole with glass lid, GREY	NO	SC1	SC1
	814276	20 cm non-stick fry pan, BLUE	NO	SC1	SC1
	814277	20 cm non-stick fry pan, GREEN	NO	SC1	SC1



KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	814278	20 cm non-stick fry pan, GREY	NO	SC1	SC1
	814279	24 cm non-stick fry pan, BLUE	NO	SC1	SC1
	814280	24 cm non-stick fry pan, GREEN	NO	SC1	SC1
	814281	24 cm non-stick fry pan, GREY	NO	SC1	SC1
	814282	28 cm non-stick fry pan, BLUE	NO	SC1	SC1
	814283	28 cm non-stick fry pan, GREEN	NO	SC1	SC1
	814284	28 cm non-stick fry pan, GREY	NO	SC1	SC1



KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	817200	Cutting board 29 x 19,5 cm, white, outside BLUE	NO	R1/B6	R1
	817201	Cutting board 29 x 19,5 cm, white, outside GREEN	NO	R1/B6	R1
	817202	Cutting board 29 x 19,5 cm, white, outside GREY	NO	R1/B6	R1
	817203	Cutting board 36 x 24,5 cm, white, outside color BLUE	NO	R1/B6	R1
	817204	Cutting board 36 x 24,5 cm, white, outside color GREEN	NO	R1/B6	R1
	817205	Cutting board 36 x 24,5 cm, white, outside color GREY	NO	R1/B6	R1



KITCHEN-TIME

Kitchen Time

Picture	Item No.	Description	RKZ	PU	PCS
	818130	Paring knife 20,5 cm white, BLUE	NO	X1/B12	X1
	818131	Vegetable knife 23,5 cm white, BLUE	NO	X1/B12	X1
	818132	Chief knife 28 cm white, BLUE	NO	X1/B12	X1
	818133	Bread knife 33 cm white, BLUE	NO	X1/B12	X1
	818134	Carving knife 33 cm white, BLUE	NO	X1/B12	X1